

INSTRUCTIONS

- When Credit Light is lit, press Credit Button and wait for machine to reset, before pressing Credit Button for additional players.
- Each player shoots one ball at a time as indicated on back glass.
- Tilt Penalty - Ball in Play - Tilt does not disqualify player.
- Making 5 Cards 10 thru Ace once; lites 1000 roll over button and bumpers, second time lites bonus scores double, third time lites special lites.
- Hitting indicated Special Target when lit scores ..1 Extra Ball.
- Hitting all four Jokers scores 1 extra ball. Maximum 1 extra ball per ball in play.