



SWITCH ADJUSTMENT:

Use slots in A-1216 mounting bracket to center bumper switch. Adjust A-8546 blade to rest lightly on bumper stem.

A 1/64-in. opening on this switch is normal. With the plunger in, the lock-in switch should show a 1/32-in. opening.